

# INSTALLATION INSTRUCTIONS

## HANGING RAILS

wardrobes  
online

WATCH HOW  
TO INSTALL  
YOUR  
WARDROBE

SCAN QR >



1. For Top Height Rail: Measure 250mm from the back of the tower/wardrobe panel. And 50mm down from the top edge of the tower.  
Screw the Rail End Bracket into the wall or tower: Use short screws to fix bracket to a tower.  
Next install the opposing hanging rail using a measuring tape and level to ensure it is installed at the same height.  
Use longer screws to fix bracket into a wall. Install wall plugs where required for a stronger install into gib.  
For Mid Height Rail: Measure 250mm from the back of the tower/wardrobe panel.  
From that mark, measure 1000mm down from the top-height-rail.



2. Measure the length between the installed rail brackets to get your rail length.  
\*Tip allow 2.5mm for each Rail End Bracket, so a 600mm wide gap between two walls you would cut the rail at 595mm.



3. Mark on rail your measured length and cut the rail using a hacksaw.  
Once cut, slot rail into rail brackets.

**Note:** because floors are sometimes not level we recommend you check heights and levels as you proceed through the installation process

